

Step 4 Call Free



- Press the “#” sign on your UNIFONE Dial pad.
- The VoipStunt Call Menu should appear on your screen.

- Press the “*” sign on your UNIFONE Dial pad to erase or delete any number or data entry you wish to change.

1. Use the UNIFONE dial pad, to dial the destination number of the party you wish to call.
2. Then press “DIAL” key to initiate your call.
3. You can lift the hand set at any moment to speak with the party you are calling.
4. Place the hand set back to the cradle to re-dial a new number or simply to end call.



Please note that when you call a number (even if it's local) you should always dial :

Country code + area code + subscriber number

No	COUNTRY	CODE
1	ARGENTINA	54
2	AUSTRALIA	61
3	AUSTRIA	43
4	BELGIUM	32
5	CANADA (LANDLINE/MOBILE)	1
6	CHILE	56
7	CHINA (LANDLINE/MOBILE)	86
8	DENMARK	45
9	FINLAND	358
10	FRANCE	33
11	GERMANY	49
12	HONG KONG (LANDLINE/MOBILE)	852
13	HUNGARY	36
14	ICELAND	354
15	IRELAND	353
16	ITALY	39
17	JAPAN	81
18	LIECHTENSTEIN	423
19	LUMEMBOURG	252
20	MALAYSIA	60
21	MONACO	377
22	NETHERLANDS	31
23	NEW ZEALAND	64
24	NORWAY	47
25	PANAMA	507
26	PUERTO RICO	787
27	PORTUGAL	351
28	SINGAPORE (LANDLINE/MOBILE)	65
29	KOREA	82
30	SPAIN	34
31	SWEDEN	46
32	TAIWAN	886
33	UNITED KINGDOM	44
34	UNITED STATES LANDLINE/MOBILE)	1
35	THAILAND	66
36	RUSSIA	7
37	PERU	51



REVISION F

Congratulations! On your purchase of State-of-the-art BROMAN™ UNIFONE series 701G

Here 's what you need to get started:

Installation and set-up time: Approximately 15 minutes.

This 4-step guide is designed to help you install your UNIFONE USB Dialer to provide you UNLIMITED FREE outgoing calls on your laptop / desktop PC

Here 's what you need to get started:

Installation and set-up time: Approximately 15 minutes.



UNIFONE USB Dialer
Allows you to connect to the multi-VOIP networks. Embedded with built-in DSP chip for better quality of sound.



Installation CD-ROM
• UNIFONE 701f Dialer Software



Laptop / Desktop PC
Requirements:
Windows operating system
Win 2000 and XP and latest OS
USB interface (USB Port)



Internet Service
• Broadband DSL or Cable
• Wi-Fi / Wireless ISP

Step 1 INSTALL Software



Load the Installation CD


- Remove CD from its casing
- Insert CD in Computer drive



1. BROMAN Start-up disk is auto-install when loaded to CD-ROM drive.
2. Please follow the instruction on the screen menu until the installation process has been completed.
3. After software installation , you can now go to step 2 (PLUG your device to USB port)

PLEASE ENSURE YOUR PC / LAPTOP IS CONNECTED ONLINE ON THE INTERNET

Step 2 PLUG your device



- Plug-in your UNIFONE USB Dialer to your Laptop/ Desktop USB interface.

1. Initially, the “RED” BROMAN e-Tone Icon will be displayed on your PC/Laptop screen lower task bar . *This will appear after Software is installed.*



2. The BROMAN e-Tone Server will automatically identify your UNIFONE device on the network Server and will locate your device and will perform User Auto-login using your BROMAN 20-Digit Subscriber Unit Number . *The “RED” icon will turn “GREEN”.*




DEVICE REGISTRATION AND ACTIVATION NORMALLY TAKE ABOUT 3~5 MINUTES

Step 3 Test the device



- Once the “GREEN” icon has stabilized and does no longer change from RED to GREEN or vice versa, you can now lift the handset from the UNIFONE base.
- The BROMAN e-Tone screen menu will appear as shown below



This message “The Client is logged on” should appear on your BROMAN menu. Your UNIFONE is now ready for use. and you can now call 37 global destinations using UNIFONE (Free & unlimited, *anytime, from anywhere within the network*).